

13 NCAC 15 .0406 UNSAFE DEVICES

If the inspector finds that the amusement device presents an imminent danger, he may attach to such device a notice warning all persons against the use thereof. Such notice shall not be removed until the device is made safe, and then only by a representative of the Director. In the meantime, the device shall not be used.

*History Note: Authority G.S. 95-111.4; 95-111.6; 95-111.9;
 Eff. August 1, 1987;
 Pursuant to G.S. 150B-21.3A, rule is necessary without substantive public interest Eff. January 5, 2016.*